

T° SENTRY MODEL 140
Digital Alarm Module

I - OPTION
ADDENDUM
4 - 20 mA

HAMPSHIRE CONTROLS CORPORATION
PO Box 516, Dover NH 03821
Tel (603) 749-9424
Toll-free (866) 496-9424
FAX (603) 749-9433

T°Sentry 140 - I Option

Calibrate/Setup Parameters

The button sequence to access the I Option Parameters is as follows:

(rhythm is: *press, press, press, release, wait*)

Press and hold **LO**, and then also **HI**, and then also **PROGRAM**

Release only **LO**, the display should say "CAL", wait for 'blip'

Now release **HI** and **PROGRAM**.

The set of 4-20mA calibration/setup parameters is as follows:

- dAO** Test parameter, simulated probe temperature
- t4** Defines the low temperature, at which 4mA is output ($t4 < t20$)
- t20** Defines the high temperature, at which 20mA is output
- c4** 4mA D/A converter calibration – please don't change
- c20** 20mA D/A converter calibration – please don't change
- OFF** Offset – should be set to zero while adjusting other parameters
- dEF** Factory set parameter – please don't change

dAO is a TEST PARAMETER ONLY. You may set it to a *simulated temperature value*. While this parameter is shown on the display the output of the 4-20mA current loop will vary as you change the dAO value based on the following equation (I_{out} value in mA):

$$I_{out} = 20 - \frac{16 \cdot (t20 - dAO)}{t20 - t4} \quad \text{where } t4 \leq dAO \leq t20$$

t4 and **t20** are set to factory defaults, but may be tailored to your application. These two values set the low and high value of the temperature range for the 4-20mA output, where $t4=4\text{mA}$ and $t20=20\text{mA}$. While these values are on the screen a fixed 4mA or 20mA will be on the output. The $t4$ value must always be less than the $t20$ value.

c4 and **c20** are factory calibrated hexadecimal values, and **usually should not be adjusted**. While the values are shown on display, 4mA and 20mA respectively are available on the 4-20mA output. Adjustment of these values requires a precision ammeter. As the value is changed, the output current will change. If needed, make small adjustments to calibrate the output to exactly 4mA and 20mA. The $c4$ value must always be less than the $c20$ value. Do not adjust $c4$ below 3mA or $c20$ above 21mA.

Offset (**OFF**) adds or subtracts a constant value from all temperature readings. You may use it as a coarse calibration adjustment. Be certain you understand the ramifications of adjusting this value before you change it from the default of zero.